

HDTV MEDIA PLAYER

COODE MEGIA PLAYER

КРАТКОЕ РУКОВОДСТВО ПОЛЬЗОВАТЕЛЯ



HDMP-300

DIGMA. Digma HDMP-300 -HDTV) USB USB: , USB 1.

2.3.,




(2) IR SENSOR:

(3) POWER:

(4) USB: USB

(5) POWER STANDBY:



DC IN:

S/PDIF: S/PDIF

VIDEO: AUDIO L/R: Y/Pb/Pr:

HDMI OUTPUT: HDMI ETHERNET PORT:

MUTE:
POWER:
MUSIC:
РНОТО:
MOVIE:
RED / GREEN / YELLOW / BLUE:

. DVD	

A:

4:

▶:

▼:

ENTER:

RETURN:

MENU:

EDIT:

INFO:

PAUSE/STEP:

PAUSE/STEP:
PLAY:
STOP:
SLOW:
PREV:
NEXT:
REPEAT:
FR:
FF:
ZOOM +/Resolution:

L/R: VOLUME +/-




1

(CRT), RCA

RCA

SCART, SCART<>RCA



2.

!

1.

2.




.1.



HD

720p. ready



PanScan, 16:9

LetterBox. Pan Scan.

!

	Digma HDMP-300	
	HDMI Auto, 480i/p, 576i/p, 720p@50Hz,	
	720p@60Hz, 1080i@50Hz, 1080i@60Hz,	
	1080p@50Hz, 1080p@60Hz, PAL, NTSC	
	,,	
	Audio L+R, CVBS,YpbPr, SPDIF, HDMI 1.3	
USB	USB Host, USB DVD-ROM,USB Wi-Fi Dongle	
038	FAT16/FAT32, NTFS, UDF,EXT3	
	FATTO/FAT32, NTF3, UDF,EXT3	
	MDEC 4 (DAT/MDC/MDEC)	
	MPEG-1 (DAT/MPG/MPEG)	
	MPEG-2	
	(MPG/VOB/ISO/IFO/TS/TP/M2TS/MTS)	
	MPEG-4 (MP4/AVI/ASP/MOV/M2TS/MTS)	
	DivX 3x/4x/5x/6x,DivX HD,DivX HD Plus	
	MKV (Divx), Xvid V, MKV(Xvid),	
	Real Video 8/9/10, HD 720@30p	
	mov, mp4, MKVH.264/AVC,MKVVC-1,	
	MKVMPEG-	
	2,FLV,VOB(DVD),ISO(DVD),IFO(DVD),	
	DAT(VCD)"	
	Dolby Digital AC3, DTS pass-through, MPEG-I	
	Layer 1/2/3, MPEG-II Layer 1/2 multichannel,	
	Real Audio, MPEG-4 HE AACv2, LPCM	
	7.1	
	MPEG-1 layer 1,2,3 (2 CH), MPEG-2 layer 1,2	
	(Multi-channel),MPEG-4 HE AACv2, WMA,	
	OGG, FLAC, AAC, Itune,	
	JPEG,BMP,TIFF,PNG,GIF	
	10/100	
	FAT16/FAT32/NTFS/UDF/EXT3	
	Samba/uPNP	
	Cambarat Ni	
	,	
	SRT, SUB, SMI, idx+sub, SSA, DVD subtile,	

	DivX subtitle
	12 /1.5
	4.8W
USB	USB 2.0, 5V~1000mA
WiFi	,
	5-8

•

Digma HDMP-300

•

•

RCA-RCA

MiniJack-Y/Pb/Pr

• 2

•

•

: http://www.digma.ru